



Notes:

1. All welds to be ground smooth
2. Verify all widths & floor to floor heights for each stair at each building & related floors
3. Red Oxide Primer

SCALE 3/8" = 1'0"

for printable file-
jscott@meyersmithinc.com

Stair Switch Back

Drwg.#

Date 03-18-02

Meyer Smith Inc.

Drawn By: JRS

800.729.9063